

01. Remove the chair from the bag and open legs most of the way but do not lock, keeping the arms down.
02. Slide seat edges into grooves in seat blocks until both sides are fully in.
03. Raise arms into upright position, making sure that the leg braces are still not locked.
04. Slip the chair back fabric over the posts and slide down fully.
05. Press leg braces into lock position on the front and back of the chair.
06. Take out the foot pedal and fix one side with screws (tall aluminum style only).
07. Setup is complete.

